






1/12















4/12






5/12





7/12



8/12







FIG. 14






10/12



11/12





12/12

FIG. 17




FIG. 18 438 -INITIATE BOOT SEQUENCE 440 **CHECK FOR BOOT** SECTOR ON HARD DRIVE 442 B00T? 444 BOOT PBS **BOOT FROM FLASH MEMORY** 446 **SERVER** REFORMAT HARD DRIVE 448 POPULATE HARD DRIVE 450 WITH PBS SOFTWARE